

Pink



High Gain Mode  
(For Headphone Out)

*After LightBar turns purple, rotate & hold the switch upwards for 8 seconds to enter high gain mode. Volume will more than double.*

Purple



Pre-High Gain Warning

Blue



Low Gain Mode  
(For Line Out)