

Pink



High Gain Mode
(For Headphone Out)

After LightBar turns purple, rotate & hold the switch upwards for 8 seconds to enter high gain mode. Volume will more than double.

Purple



Pre-High Gain Warning

Blue



Low Gain Mode
(For Line Out)